

## KANE INSTRUMENTATION LTD.

Specializing in Instrumentation and Oilfield Equipment

## **Crane Scale Weight Indicator**

## **Features**

- Ideal for construction, dockside, offshore drilling, material replenishment, and salvage operations.
- Helps prevent buckled booms, costly, and dangerous crane accidents.
- Large 8.5" dial is simple to see.
- Gauge can be mounted inside or outside of the cab within easy view of the crane operator.
- Electronic "All In One" version also available (can be ordered with remote display).
- Dial capacities up to 300,000 lbs.

## **How To Order**

- Crane Make and Model
- Boom Length (distance from center line of boom foot pin to center of line of boom point hoist sheave pin)
- Number of Parts of Line
- Wire Rope Size
- Capacity of Crane at Boom Length and Parts Line Specified
- Distance from Boom Foot Pin to Axis of Rotation (only needed if Radius Sensor is being used)
- Radius and Capacity Data as Shown on Manufacturer's Rating Card (only needed if Radius Sensor is being used)



